


THE FLOOR PLAN

101-5 Ballantine Road

Bernardsville, New Jersey




FIRST FLOOR

NOT TO SCALE - This floor plan is provided for illustration purposes only.
Room positions and dimensions are approximate and should be independently measured for accuracy

THE FLOOR PLAN

101-5 Ballantine Road


Bernardsville, New Jersey



SECOND FLOOR

NOT TO SCALE - This floor plan is provided for illustration purposes only.
Room positions and dimensions are approximate and should be independently measured for accuracy

THE FLOOR PLAN
101-5 Ballantine Road
Bernardsville, New Jersey




NOT TO SCALE - This floor plan is provided for illustration purposes only.
Room positions and dimensions are approximate and should be independently measured for accuracy

THE FLOOR PLAN

101-5 Ballantine Road


Bernardsville, New Jersey



LOWER LEVEL

NOT TO SCALE - This floor plan is provided for illustration purposes only.
Room positions and dimensions are approximate and should be independently measured for accuracy

THE FLOOR PLAN
101-5 Ballantine Road
Bernardsville, New Jersey



NOT TO SCALE - This floor plan is provided for illustration purposes only.
Room positions and dimensions are approximate and should be independently measured for accuracy